



APPLICATION INSTRUCTIONS

SURFACE GUARD TAPE:

PREPARATION:

For best results, apply at temperatures between 50F-80F. Surface must be clean and free of dirt and/or wax prior to application. Use sharp scissors to cut Surface Guard to size before removing liner, experiment with a small piece first.

DRY APPLICATION:

Remove paper liner slowly as Surface Guard is applied. Squeegee into position very slowly. The slower the better. Again, experiment first.

WET APPLICATION:

Spray a mixed solution of soap and water on the surface to be applied over. Remove the liner, apply, position into place and squeegee out bubbles. Any bubbles can be punctured with a razor tip. Allow 24 hours to dry.

Allstar Performance 8300 Lane Dr., Watervliet, MI 49098

Phone: (269) 463-8000 Fax: (800) 772-2618 www.allstarperformance.com

Form 1069

Page 1 of 1

Rev. 102908



APPLICATION INSTRUCTIONS

SURFACE GUARD TAPE:

PREPARATION:

For best results, apply at temperatures between 50F-80F. Surface must be clean and free of dirt and/or wax prior to application. Use sharp scissors to cut Surface Guard to size before removing liner, experiment with a small piece first.

DRY APPLICATION:

Remove paper liner slowly as Surface Guard is applied. Squeegee into position very slowly. The slower the better. Again, experiment first.

WET APPLICATION:

Spray a mixed solution of soap and water on the surface to be applied over. Remove the liner, apply, position into place and squeegee out bubbles. Any bubbles can be punctured with a razor tip. Allow 24 hours to dry.

Allstar Performance 8300 Lane Dr., Watervliet, MI 49098

Phone: (269) 463-8000 Fax: (800) 772-2618 www.allstarperformance.com

Form 1069

Page 1 of 1

Rev. 102908