



## Switch Panel

### INSTALLATION INSTRUCTIONS

#### **Allstar Performance Switch Panel Model 80150**

- Connect Red wire from ignition switch to a "+" positive battery connection, or the switched side of the battery disconnect switch.
- Connect Red wire from the start button to the starter solenoid.
- Connect Black wire from the ignition switch to the magneto.
- Connect White wire from the accessory to the "+" positive side of accessory to be used. (i.e. water pump, cooling fan, etc.)

To protect wires on the switch panel from the elements, seal connections on the back of the panel with a good quality silicone.

**Allstar Performance 8300 Lane Dr., Watervliet, MI 49098**

**Phone: (269) 463-8000 Fax: (800) 772-2618 [www.allstarperformance.com](http://www.allstarperformance.com)**

Form 1017

Rev. 020408



## Switch Panel

### INSTALLATION INSTRUCTIONS

#### **Allstar Performance Switch Panel Model 80150**

- Connect Red wire from ignition switch to a "+" positive battery connection, or the switched side of the battery disconnect switch.
- Connect Red wire from the start button to the starter solenoid.
- Connect Black wire from the ignition switch to the magneto.
- Connect White wire from the accessory to the "+" positive side of accessory to be used. (i.e. water pump, cooling fan, etc.)

To protect wires on the switch panel from the elements, seal connections on the back of the panel with a good quality silicone.

**Allstar Performance 8300 Lane Dr., Watervliet, MI 49098**

**Phone: (269) 463-8000 Fax: (800) 772-2618 [www.allstarperformance.com](http://www.allstarperformance.com)**

Form 1017

Rev. 020408